


ENGAGE

**TO ENGAGE:**


**1. ANGLE**

- Start by engaging the plank on the long side at a 45 degree angle.




**4. DROP**

- Press along the short side until you hear or feel the plank “Click” into place.




**2. SLIDE**

- Slide the plank to the left until the short sides align.




**5. SECURE**

- To secure the locking system and make flush, gently tap with a soft-faced hammer.




**3. CHECK**

- Ensure the click system is firmly locked along the long edge, using a tapping block if necessary. No gaps should be visible.



**NOTE**

- If planks are not completely flush, repeat step 5.




DISENGAGE

**TO DISENGAGE:**


**1. SLIDE**

- Slide the planks in the opposite direction to disengage.



**2. DROP**

- If planks are not disengaging, then tap with a soft-faced hammer and then slide planks.



**WARNING!**

- Do not angle the planks to disengage. The locking system will break.

